





Dunlop AGO/40 Optical Alignment Gauge Spare Parts List

Part No.	Quantity Per Gauge	Description
DA3	1	Bottom Dial
DA4	1	Top Dial
DA5	2	Balance Leg
DA7	1	Quadrant Arm
DA8	1	View Box Cover
DA9	1	View Box Tube Top
DA10	1	View Box
DA11	1	Knob
DA12	1	Target Plate
DA13	1	Guide Strip with Wing Nuts
DA14	1	Pointer with Weld Screw
DA15	6	Foot
DA16	1	View Box Window
DA18	4	Contact Bar
DA19	4	Eye Bolt
DA20	4	Wing Nut
DA21	1	Scale Plate
DA23	1	View Box Mirror with Tape
DA24	1	Lens
DA25	1	Eye Piece
DA30	1	Locking Ring
DA33	5	Thumb Screw, M8
DA42	2	Countersunk Screw, M4
DA44	4	Standard Nut, M3

Sub-Assemblies

Assembly Part No.	Quantity Per Gauge	Description
DA49	1	Mirror Bracket Assembly
DA50	1	View Box Assembly
DA51	1	Calculator Assembly

